

**FAX 610-789-7300**

[WWW.NECCDELIVERS.COM](http://WWW.NECCDELIVERS.COM)

**800-227-9800**

***Eliminate the need for charts and pens!!***

**HOBO™ Data Loggers can do it all!**

- Portable
- Easily configured
- Mounts almost anywhere
- Temperature, RH, Motor On/Off, State (Open/Close)
- Stores over 7000 measurements



ORDERING INFORMATION					
ORDER #	Temperature -4 to 158°F	Relative Humidity 25 to 95%	Motor On/Off (Vibration)	Motor Current On/Off	Contact Open/Close Status
H08-001-02	1 Channel	—	—	—	—
H08-002-02	2 Channel	—	—	—	—
H08-003-02	1 Channel	1 Channel	—	—	—
H08-007-02	2 Channel	2 Channel	—	—	—
H06-003-02	—	—	Yes	—	—
H06-004-02*	—	—	—	Yes	—
H06-001-02	—	—	—	—	Yes
H08-006-04* (4 Channel)	Yes	Yes	—	Yes	Yes

\* Requires external sensor (listed in accessories chart)

ACCESSORIES	
ORDER #	DESCRIPTION
BCP3.6-DL	Boxcar 3.6 Software Starter Kit
BCP4.0-DL	Boxcar Pro 4.0 Software Kit
TMC6-HA	Temperature Sensor w/6' Cable
CT-A	Current Sensor w/.5" Window
CT-B	Current Sensor w/.75" Window
CT-C	Current Sensor w/1.0" Window
CABLE-4.20mA	4-20mA Cable
CABLE-2.5-STEREO	Voltage Input Cable

**Welcome to the World's Largest HVAC Control and Building Automation Parts Database**

- Over **130,000** controls and accessories
- Search by model number, noun or any brand
- Competitive **cross-reference**
- Substitute old parts to new
- Factory specifications archives
- **Factory-trained** support staff
- Technical training opportunities
- Fast **worldwide** delivery

**Try it NOW! [www.neccdelivers.com](http://www.neccdelivers.com)**  
**610 449-9800 Fax 610 789-7300**